


GRAUGEAR®


5.25" Multi Front Panel

with USB Hub, Card Reader and Audio


www.graugear.de

G-MP03CR-AU

Package Contents





Features




- Fits into a standard 5.25" drive bay
- 2x USB Type-C with a transfer rate up to 10 Gbit/s
- 2x USB Type-A with a transfer rate up to 10 Gbit/s
- 1x Micro SD and 1x SD Card Reader slot
- 1x microphone and 1x earphone port
- Supports Windows

Specification

- Connection to host computer: 1x USB 3.0 host (19 pin) header
1x USB 3.2 Gen 2 A-Key (20 pin) header
- Connection to power supply: 1x SATA 15-pin Power header
- External interface : 2x Type-C + 2x USB Type-A
1x microphone, 1x earphone
1x SD & 1x micro SD card reader slot
- Dimension: (W x D x H) 148 x 86 x 41 mm
- Cable length: 65 cm (USB 3.2 Gen 2 A-Key); 65 cm (USB 3.0 host (19-pin))
15 cm (SATA 15-pin Power)
- PC connection : 5.25" bay
- Weight : 220g



Installation



Safety information

For your own safety and to avoid physical damage as well as damage to property, equipment and loss of data, please observe the following instructions

Warning signs

DANGER

You will be alerted to a potentially hazardous situation which may result in serious injury or even death!

WARNING

You will be alerted to a potentially dangerous situation that could result in serious injury, even death!

CAUTION

You will be alerted to a potentially dangerous situation that may result in minor injury!

IMPORTANT

Your attention is drawn to a possible situation that could result in property damage and possibly environmental damage or disrupt operations.

IMPORTANT

Irreversible damage is possible!

WARNING

Please be sure to read the operating instructions.

Use the product only if all specifications and requirements are met.

Always perform a data backup of storage media to be installed.

Always perform a data backup before commissioning.

Always perform a data backup before connecting new hardware.

Only use the accessories supplied with the product.

Cleaning of the product

Damaging cleaning agents - scratches, color changes, moisture damage or short circuit on the device.

IMPORTANT

Take the product out of operation before cleaning.

Do not use aggressive / harsh cleaners.

Make sure that there is no residual moisture in the device after cleaning.

It is best to use an anti-static cloth for cleaning.

2. Possible dangers during assembly due to sharp-edged components!

Cutting and hand injuries possible during assembly.

CAUTION

Please read the operating instructions before assembly.

Avoid contact with sharp pointed objects.

Do not use force during assembly.

Only use suitable tools supplied with accessories and tools.

3. Danger of overheating due to insufficient ventilation of the product/power supply!

The device symbol on the product or packaging indicates that this product must be disposed of with the household waste if necessary, remove old batteries/rechargeable batteries and send them for recycling or disposal. According to the Waste Electrical and Electronic Equipment (WEEE) Directive, you may not dispose of this product and any batteries/rechargeable batteries it may contain in your normal household waste.

If you wish to dispose of this product/batteries, please take them to a suitable disposal point (recycling collection point in your city) or return them to your point of purchase.

IMPORTANT

If you have any questions, please do not hesitate to contact our support at support@graugear.de or visit our website www.graugear.de.

GRAUGEAR®

Need Help?



©Copyright 2021 by CHA-B GmbH. All Rights Reserved
Ostfeldstrasse 12, 9144 Ammerbuch / Germany
info@cha-b.de

Made in China

Windows and Windows logo are registered trademarks of Microsoft Corporation.

Apple, Mac, Mac OS, Mac OS X, and Macintosh are registered trademarks of Apple Computer, Inc.

