
# **GRAUGEAR**

## **Multi Front Panel**

with USB Hub and Card Reader



### **Package Content**

**Key Features** 

Supports Windows

**Specification** 

Cable lenath: 60 cm

• Weight: 170g

• PC connection: 3.5" bay

Connection to host computer:

1x Micro SD +1x SD Card Reader

Dimension: (W x D x H) 102 x 102 x 25 mm

Micro SD / SD Card Reader

• Fits into a standard 3.5" (8.89 cm) bay















 2x USB Type-A and 1x USB Type-C<sup>®</sup> with a data transfer rate of up to 5 Gbit/s System requirements: 1x internal USB 3.0 host (19-pin) header,

1x USB 3.0 (19-pin) header + 1x USB 3.2 Gen 2 Key A (20-pin) header

Micro SD Card Reader

1x USB Type-C® with a data transfer rate of up to 10 Gbit/s

1x internal USB 3.2 Gen 2 Key A host (20-pin) header

• External Connectors: 2x USB Type-A + 2x Type-C® and










USB 3.2 Gen2 Type-C®


SD Card USB 3.2 Gen1 Type-C®



Installation




















Plug the USB 3.0 (19-pin) header 4) into the 20-pin USB connector and the USB 3.2 Key A (20-pin) header into the 20-pin Kev A on the motherhoard

## Safety information

Please read carefully the following information to prevent injuries, damage to material and device as well as data loss:

#### Warnina levels

Signal words and safety codes indicate the warning level and provide immediate information in terms of the probability of occurrence as well as the type and severity of the consequences if the measures to prevent hazards are not complied with.



Warns of a directly hazardous situation causing death or serious iniury



Warns of a potentially hazardous situation that may cause death or serious injury.



Warns of a potentially hazardous situation that may



Warns of a potential situation that may cause material or environmental damage and disrupt operative processes.

#### 1. Risk of electrical shock



Contact with parts conducting electricity

Risk of death by electrical shock

- · Read the operating instructions prior to use
- . Make sure the device has been de-energised prior to working on it
- Do not remove contact protection panels
- Avoid contact with conducting parts
- . Do not bring plug contacts in contact with pointed and metal objects
- Use in intended environments only
- . Operate the device using a power unit meeting the specifications of the type plate only!
- Keep the device/power unit away from humidity, liquid, vapour and dust.
- . Do not modify the device
- . Do not connect the device during thunderstorms
- · Approach specialist retailers if you require repairs

#### 2. Hazards during assembly(if intended)



### Sharp components

Potential injuries to fingers or hands during assembly (if intended)

- Read the operating instructions prior to assembly Avoid coming into contact with sharp edges or pointed components
- . Do not force components together
- Use suitable tools
- Use potentially enclosed accessories and tools only

## Safety information


#### 3. Hazards caused by a developent of heat

#### Insufficient device / power unit ventilation

Overheating and failure of the device / power unit.

- Prevent externally heating up components and ensure an exchange of air.
- Do not cover the fan outlet and passive cooling elements
- Avoid direct sunlight on the device/power unit.
- Guarantee sufficient ambient air for the device/power unit
- Do not place objects on the device / power unit

#### 4. Hazards caused by very small parts and packaging



- Keep small parts and accessories away from children
- Store/dispose of plastic bags and packaging in an area that is inaccessible to children Do not hand over small parts and packaging to children

#### 5. Potential data loss

#### Data lost durina commissionina Potentially irreversible data loss

- Always comply with the information in the operating instructions/quick installation guide
- Exclusively use the product once the specifications have been met
- Back up data prior to commissioning
- Back up data prior to connecting new hardware.
- Use accessories enclosed with the product

#### 6. Cleaning the device

#### Harmful cleaning agents

IMPORTANT Scratches, discolouration, damage caused by moisture or short circuit in the device

- Disconnect the device prior to cleaning
- Agaressive or intense cleaning agents and solvents are unsuitable
- Make sure there is no residual moisture after cleaning.
- We recommend cleaning devices using a dry, anti-static cloth

#### 7. Cleaning the device



Environment pollution, unsuitable for recycling IMPORTANT Potential environmental pollution caused by components,

This icon on product and packaging indicates that this product must not be disposed of as part of domestic waste. In compliance with the Waste Electrical and Electronic Equipment Directive (WEEE) this electrical device and potentially included batteries must not be disposed of in conventional, domestic waste or recycling waste. If you would like to dispose of this product and potentially included batteries, please return it to the retailer or your local waste disposal and recycling point.

If you have any questions, please do not hesitate to contact our support at support@araugear-usa.com or visit our website at www.araugear-usa.com **GRAUGEAR** 



© Copyright 2022 by Detron International Co., Ltd

8F., No. 67, Anping Road, Zhonghe District, New Taipei City, Taiwan, R.O.C.

Windows and the Windows logo are registered trademarks of Microsoft Corporation. Apple, macOS, MAC, iTunes and Macintosh are registered trademarks of Apple Computer.